

User's guide

Before using your pet cam, please read the instructions in this guide carefully and keep it for future reference.

Index	Page
Contents and description of the EYENIMAL Pet Cam	10
First use of the camera.....	11
How to turn the camera on/off and How to record	12
Recording sessions.....	12
How to view/ delete/ download videos	12
Share your videos	13
Cautions for use	13
Maintenance	13
Troubleshooting	14
Technical specifications.....	14
Warranty	14
Warranty conditions.....	14
Disposing or recycling of your device at the end of its life	15

● Contents and description of the EYENIMAL Pet Cam

■ Contents

- 1 EYENIMAL Pet Cam
- 1 USB cable
- This user's guide

■ Description

- on/off
- lens
- light indicator
- USB port transfer the recording and recharge the battery



- fastening clip
- sticker to write down your personal details
- reset button



The video camera is both PC and Mac compatible.

The minimum system requirements are as follows:

- PC: Operating system Microsoft Windows 2000
- Mac: Operating system OSX

● **First use of the camera**

■ **Charging the camera's battery**



To charge the battery, the camera must be turned off.

The battery must be charged for at least 8 hours before the video camera is used for the first time.

To charge the battery, remove the protection tab under your camera, (See diagrams § Description). Connect the video camera (turned off) to your PC using the cable provided. For the following charges, charge for 5 hours for a full battery. The computer must be turned on or on standby to charge.

■ **ID sticker**

Should your pet or the camera be lost, there is an area at the back of the camera where pet owners can handwrite their names and contact details on the provided sticker (See diagrams § Description).

■ **Warning**

Pet owners are advised to observe the usual precautions associated with the use of a collar. It is recommended that pets, and especially cats be fitted with a safety or breakaway-type collar to prevent collar injury or strangulation : safety collars either made entirely of stretchy elastic material or, using the nylon-type, consist of two parts connected by an expandable elasticated portion.

- Metal and other rigid-type collars should never be used.
- Remember to check your pet's collar regularly to ensure it fits; it will need adjusting As your pet grows.

■ **How to attach the camera to your pet's collar and fitting the collar**

The fastening clip has been specially designed so the camera can fit on collars from 3/8 to 1.2 inch (from 1 to 3cm wide). To attach the camera to your pet collar, slide the collar through the tab of the fastening clip and make sure that the camera is securely in place.

The collar should always be fitted so it is comfortable but not too loose. The rule of thumb is that there should be enough room to fit two fingers between your pet's neck and the collar.

After having fitted the collar around your pet's neck, adjust the angle of the camera to ensure that the lens is perpendicular to the ground.

● How to turn the camera on/off and How to record

Before the first use, remove the plastic protection of the camera lens.

To turn on the camera, press and hold the button located on the side of the unit for 5 seconds (See diagrams § Description). When the blue light indicator is on and stays lit: the camera is turned on.

To start recording, press the same button again briefly. The blue light indicator will start blinking when the camera is recording.

To stop the recording press the same button again briefly. To turn off the camera, press and hold the button for 5 seconds.

In case of camera malfunction, press the « Reset » button (See diagrams § Description). **The « Reset » button allows you to restore all factory settings.**

CAUTION: if you do not use the camera for an extended period, you may need to reset it in order to restart.

● Recording sessions

The memory capacity allows the camera to record continuously for 2.5 hours. Videos are divided into sessions of 30 min. When the memory is full, the camera turns itself off automatically and you cannot record any more new sessions. It is then necessary to delete all or any of the sessions to be able to free memory to record again.

● How to view/ delete/ download videos



To proceed to these operations, the camera must be turned off.

Connect the video camera (turned off) to your PC using the cable provided. Your computer should automatically recognize the camera. You can then view, delete or transfer the recordings using the media player of your choice, available on your computer.

IMPORTANT: In some instances, certain computers may not detect the camera on the 1st try. In that case, disconnect the USB cable from your computer and repeat the steps. Be sure to verify that your camera is correctly turned off.

● Share your videos

Share your favorite videos of your cat or your dog with thousands of people all over the world. Post videos on our official Facebook page : www.facebook.com/eyenimal or send us a link of your video at contact@eyenimal.com and we will put the best videos on our website.



Image rights and privacy:

The online publishing of images and videos without the prior written consent of the people appearing in them and who can be identified is strictly prohibited. The publisher of the image or video takes full liability for any complaints that may incur.

● Cautions for use

■ The video camera has a casing allowing it to be used in a humid environment. However, the camera has not been designed to be fully submerged in water or any other liquid. Moreover, immersion can represent certain risks for the user.



Any damages caused by immersion will not be covered by the warranty.

- Do not open or dismantle the camera. **It will void the warranty.**
- Do not throw your camera away with household trash (See § Disposing or recycling of your device at the end of its life).
- Keep the camera out of reach of children. To use the camera, an adult supervision is strongly recommended.
- We recommend you not to use your camera below 0°C. The battery life will be reduced slightly in lower temperatures.

● Maintenance

Avoid cleaning the unit with volatile liquids such as solvents or cleaning fluids. Use a soft cloth and neutral detergent. Do not put your camera directly under the faucet.

For the camera's lens, use dry cloth made for that purpose.

● Troubleshooting

Should your camera stop working or develop an issue, first, read this user's guide. Then, check the battery and that you are using the product correctly.

In case of issues, proceed to "reset" the camera by pressing the « Reset » button and holding it for 5 seconds (See diagrams § Description). The "Reset" button allows you to restore all factory settings.

If the problem persists, contact your distributor or check out www.eyenimal.com for customer care.

Depending on the extent of the issue, you may have to return your product for service and repair.

● Technical specifications

- 4 GB built-in Flash memory
- Voice recorder with built-in microphone
- Battery life: 2.5 hours
- Transfer and battery charging via USB connection
- Weight : 35 g
- Dimensions: H x L x D : 60 x 45 x 15 mm
- Video capture resolution: 680 x 480 pixels
- Compatible with Microsoft Windows 2000, XP, Windows 7, Vista, Mac OS 10.x et Linux
- Recording format : AVI
- Video capture at 29 frames per second
- Use temperature: between 0°C and + 40°C

● Warranty

FELIS INNOV' warranty the product against all production defects for 1 year after purchase. All postage and packing charges will be the purchaser's sole responsibility.

● Warranty conditions

1. The WARRANTY will be effective only with a proof of purchase (invoice or sales receipt). The warranty is exclusive to the original purchaser.

2. This warranty does not cover the following:

- changing the battery,
- direct or indirect problems incurred when sending the product back to the distributor or to FELIS INNOV',
- damage to the product caused by:
 - negligence or incorrect use (ex: bites, breakage, cracking),
 - misuse from not following directions
 - repairs performed by unauthorized persons.
- loss or theft.

3. If the product is found to be defective, FELIS INNOV' will either decide to repair or to replace it.

4. No claim may be made against FELIS INNOV', particularly in relation to incorrect use or breakdown.

5. FELIS INNOV' reserves the right to modify the characteristics of its products with a view to making technical improvements or to complying with new regulations.

6. The information contained in this guide may be subject to amendment without prior notice.

7. Photos and drawings are not contractual.

● **Disposing or recycling of your device at the end of its life**

The pictogram  which appears on your product means that this device cannot be disposed of with common household items.

You have to bring the device to a collection location suitable for treatment, development, recycling of electronic waste or bring it back to your distributor.


EYENIMAL
A LIVING ADVENTURE

www.eyenimal.com